

i02643671

# Maintenance Interval Schedule

## When Required

Battery - Replace .....	51
Battery or Battery Cable - Disconnect .....	52
Engine - Clean .....	55
Engine Air Cleaner Element (Dual Element) - Clean/Replace .....	56
Engine Air Cleaner Element (Single Element) - Inspect/Replace .....	58
Fuel System - Prime .....	62
Severe Service Application - Check .....	66

## Daily

Cooling System Coolant Level - Check .....	54
Driven Equipment - Check .....	55
Engine Air Cleaner Service Indicator - Inspect .....	59
Engine Oil Level - Check .....	59
Fuel System Primary Filter/Water Separator - Drain .....	63
Walk-Around Inspection .....	68

## Every 50 Service Hours or Weekly

Fuel Tank Water and Sediment - Drain .....	64
--------------------------------------------	----

## Every 500 Service Hours or 6 Months

Alternator and Fan Belts - Inspect/Adjust/ Replace .....	50
-------------------------------------------------------------	----

## Every 500 Service Hours or 1 Year

Battery Electrolyte Level - Check .....	51
Cooling System Supplemental Coolant Additive (SCA) - Test/Add .....	55
Engine Air Cleaner Element (Dual Element) - Clean/Replace .....	56
Engine Oil and Filter - Change .....	60
Fuel System Filter - Replace .....	62
Hoses and Clamps - Inspect/Replace .....	64
Radiator - Clean .....	66

## Every 1000 Service Hours

Alternator - Inspect .....	50
Engine Valve Lash - Inspect/Adjust .....	61
Starting Motor - Inspect .....	67
Turbocharger - Inspect .....	67

## Every 2000 Service Hours

Engine Mounts - Inspect .....	59
-------------------------------	----

## Every 2 Years

Cooling System Coolant (Commercial Heavy-Duty) - Change .....	52
------------------------------------------------------------------	----

## Every 3000 Service Hours

Water Pump - Inspect .....	69
----------------------------	----